


# PACKAGING TIPS

## DEFECTS

### USE AN APPROPRIATE BOX



Use an appropriately sized box

### REMOVE OLD LABELS



Remove all labels and stickers if you re-use a box

### USE AN OUTER BOX



The product's retail packaging is not suitable for transport

### USE A STURDY BOX




Always use an outer box of good, sturdy quality

### PROTECT THE PRODUCTS



Use filling under, around and between the products

### FILL ALL EMPTY SPACES




Fill the box by placing filling on top of the products

### ADD THE FORM



Print the fully completed defects form and add it to the box

### CAREFULLY SEAL THE BOX USING TAPE




Use the 'H taping Method' to carefully seal the box  
Use strong, wide tape (> 5 cm)

### PREPARE THE PACKAGE IN GOOD TIME



Once notification is received, the package will be immediately reported for collection

### MAXIMUM WEIGHT AND DIMENSIONS



Maximum weight: 31.5 kg  
Maximum length (A): 1.75 metres  
Maximum size: 3 metres

#### Calculation of size

1x side A  
+ 2x side B  
+ 2x side C  
= size of the package

The courier service has established guidelines for the maximum weight and dimensions of each package

### DO NOT BE FRUGAL WITH PACKAGING



Never be frugal when it comes to packaging you package. In most cases, the financial consequences of damage to the contents exceed the costs of the packaging material